



RANCH RAIL GATE ASSEMBLY INSTRUCTIONS

NOTES:

1. Individual components are wrapped in stretch wrap and identified appropriately.
2. Separate gate material from rest of fence package material.
3. Inspect material for damage and notify **BLACKLINEHHP PRODUCTS** immediately if damage or other issues found.
4. All hardware and fasteners will be individually packaged as well.



BLACKLINEHHP PRODUCTS, LLC

1325 MARIETTA AVE., BELLINGHAM, WA 98226
360-398-1824 (OFFICE); INFO@BLACKLINEHHP.COM
WWW.BLACKLINEHHP.COM

STEP 1

Insert horizontal rails into the gate stiles (uprights). Make sure that rails are fully inserted into gate stiles. To ensure they are fully inserted; measure the width of the gate from outside of one gate stile to the outside of the other. This should match the width of gate ordered.

Please note that small variances may be present.

STEP 2

Install Qty. 2 TEK screws through the pre-installed gate pockets of the gate stile (upright) and into the horizontal rails. Complete this step in each end of each gate stile. There will be a total of 8 screws.

Space screws as shown as best as possible.



BLACKLINEHHP PRODUCTS, LLC

1325 MARIETTA AVE., BELLINGHAM, WA 98226
360-398-1824 (OFFICE); INFO@BLACKLINEHHP.COM
WWW.BLACKLINEHHP.COM

STEP 3

Lay gate down flat and place pre-cut gate struts on face of gate. Install provided TEK screws into each pre-drilled hole in the struts and into the horizontal rails. **When using a drill, place the clutch on a low setting set the speed to LOW to make sure screws do not get stripped out.**

Snap provided 5/8" button plugs on each pre-drilled strut hole. Flip gate over and do the same to the opposite side.



BLACKLINEHHP PRODUCTS, LLC

1325 MARIETTA AVE., BELLINGHAM, WA 98226
360-398-1824 (OFFICE); INFO@BLACKLINEHHP.COM
WWW.BLACKLINEHHP.COM

STEP 4

Place 4x4 gate stile (upright) caps onto gate. Below is how your gate should look. The gate can now be installed. **Enjoy!**



BLACKLINEHHP PRODUCTS, LLC

1325 MARIETTA AVE., BELLINGHAM, WA 98226
360-398-1824 (OFFICE); INFO@BLACKLINEHHP.COM
WWW.BLACKLINEHHP.COM